## **OWNER'S MANUAL**





For proper operation, please read and keep this manual carefully.
Designed by Cooper&Hunter International Corporation, FL Miami, USA

www.cooper and hunter.com


#### **EXPLANATION OF SYMBOLS**

⚠ WARNING ⚠	This symbol indicates the possibility of death or serious injury.
① CAUTION ①	This symbol indicates the possibility of injury or damage to property.
NOTICE	Indicates important but not hazard-related information, used to indicate risk of property damage.

#### **EXCEPTION CLAUSES**

Manufacturer will bear no responsibilities when personal injury or property loss is caused by the following reasons:


- 1. Damage the product due to improper use or misuse of the product;
- Alter, change, maintain or use the product with other equipment without abiding by the instruction manual of manufacturer;
- 3. After verification, the defect of product is directly caused by corrosive gas;
- 4. After verification, the defects are due to improper operation during transportation of product;
- Operate, repair, maintain the unit without abiding by instruction manual or related regulations;
- 6. After verification, the problem or dispute is caused by the quality specification or performance of parts and components that produced by other manufacturers;
- 7. The damage is caused by natural calamities, bad using environment or force majeure.

If it needs to install, move or maintain the air conditioner, please contact dealer or local service center to conduct it at first. Air conditioner must be installed, moved or maintained by appointed unit. Otherwise, it may cause serious damage or personal injury or death.

When refrigerant leaks or requires discharge during installation, maintenance, or disassembly, it should be handled by certified professionals or otherwise in compliance with local laws and regulations.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

#### ХОЛОДОАГЕНТ



- To realize the function of the air conditioner unit, a special refrigerant circulates in the system. The used refrigerant is the fluoride R32, which is specially cleaned. The refrigerant is flammable and inodorous. Furthermore, it can lead to explosion under certain conditions. But the flam-mability of the refrigerant is very low. It can be ignited only by fire.
- Compared to common refrigerants, R32 is a nonpolluting refrigerant with no harm to the ozonosphere. The influence upon the greenhouse effect is also lower. R32 has got very good thermodynamic features which lead to a really high energy efficiency. The units there fore need a less filling.



Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacture. Should repair be necessary, contact your nea rest authorized Service Centre. Any repairs carried out by unqualified personnel may be dangerous. The appliance shall be stored in a room without continuously operating ignition sources. (for example: open flames, an operating gas appliance or an operating electric heater.) Do not pierce or burn. Appliance shall be installed, operated and stored in a room with a floor area larger than Xm<sup>2</sup>.

(Please refer to table «a» in section of «Safety operation of flammable refrigerant» for space X.) Appliance filled with flammable gas R32. For repairs, strictly follow manufacturer's instructions only. Be aware that refrigerants may not contain an odor . Read specialist's manual.





This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

Hereby, Our company, declares that this Air Conditioner is in compliance with the essential requirement and other relevant provisions of RE Directive 2014/53/EU. A copy of the full DoC is attached. Wireless frequency range: 2412MHz – 2472MHz Maximum Transmit Power: 18dBm



#### R32: 675

This marking indicates that this product should not be disposed with other house hold wastes. To prevent possible harm to the environment or human health

from uncontrolled waste throu ghout the EU. To prevent possible harm to the environment or human health.

From uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling. If it needs to install, move or maintain the air conditioner, please contact dealer or local service center to conduct it at first. Air conditioner must be installed, moved or maintained by appointed unit. Other wise, it may cause serious damage or personal injury or death.

2

# SAFETY OPERATION OF FLAMMABLE REFRIGERANT

## Qualification requirement for installation and maintenance man

- Delta All the work men who are engaging in the refrigeration system should bear the valid certification awarded by the authoritative organization and the qualification for dealing with the refrigeration system recognized by this industry. If it needs other technician to maintain and repair the appliance, they should be supervised by the person who bears the qualification for using the flammable refrigerant.
- ▶ It can only be repaired by the method suggested by the equipment's manufacturer.

#### **Installation notes**

- ➤ The air conditioner must be installed in a room that is larger than the minimum room area. The minimum room area is shown on the nameplate or following table a.
- ▶ It is not allowed to drill hole or burn the connec-tion pipe.
- ▶ Leak test is a must after installation.

#### Table A - Minimum room area (m<sup>2</sup>)

Charge amount (kg)	Floor location	Window mounted	Wall mounted	Ceiling mounted
≤1.2	/	/	/	/
1.3	14.5	5.2	1.6	1.1
1.4	16.8	6.1	1.9	1.3
1.5	19.3	7	2.1	1.4
1.6	22	7.9	2.4	1.6
1.7	24.8	8.9	2.8	1.8
1.8	27.8	10	3.1	2.1
1.9	31	11.2	3.4	2.3
2	34.3	12.4	3.8	2.6
2.1	37.8	13.6	4.2	2.8
2.2	41.5	15	4.6	3.1
2.3	45.4	16.3	5	3.4
2.4	49.4	17.8	5.5	3.7
2.5	53.6	19.3	6	4

#### Maintenance notes

- ▶ Check whether the maintenance area or the room area meet the requirement of the nameplate.
  - It's only allowed to be operated in the rooms that meet the requirement of the nameplate.
- ▶ Check whether the maintenance area is well-ventilated.
  - The continuous ventilation status should be kept during the operation process.
- ▶ Check whether there is fire source or potential fire source in the maintenance area.
  - The naked flame is prohibited in the maintenance area; and the "no smoking" warning board should be hanged.
- ▶ Check whether the appliance mark is in good condition.
  - Replace the vague or damaged warning mark.

#### Welding

- ▷ If you should cut or weld the refrigerant system pipes in the process of maintaining, please follow the steps as below:
  - A. Shut down the unit and cut power supply
  - B. Eliminate the refrigerant
  - C. Vacuuming
  - D. Clean it with N2 gas
  - E. Cutting or welding
  - F. Carry back to the service spot for weldin
- ▶ The refrigerant should be recycled into the specialized storage tank.
- ▶ Make sure that there isn't any naked flame near the outlet of the vacuum pump and it's wellventilated.



#### Filling the refrigerant

- ➤ Use the refrigerant filling appliances specialized for R32. Make sure that different kinds of refrigerant won't contaminate with each other.
- ➤ The refrigerant tank should be kept upright at the time of filling refrigerant.
- ▶ Stick the label on the system after filling is fin-ished (or haven't finished).
- Don't overfilling. 

  ▷
- After filling is finished, please do the leakage detection before test running; another time of leak detection should be done when it's removed.

# Safety instructions for transportation and storage

- ▶ Please use the flammable gas detector to check before unload and open the container.
- ▶ No fire source and smoking.
- ▶ According to the local rules and laws.

#### **SAFETY PRECAUTIONS**

### $\bigwedge$

#### WARNING



#### Installation

- ▶ Installation or maintenance must be performed by qualified professionals.
- ▶ The appliance shall be installed in accordance with national wiring regulations. According to the local safety regulations, use qualified power supply circuit and circuit breaker.
- ▷ All wires of indoor unit and outdoor unit should be connected by a professional. Be sure to cut off the power supply before proceeding any work related to electricity and safety.
- ▶ Make sure the power supply matches with the requirement of air conditioner.
- ▷ Unstable power supply or incorrect wiring may result in electric shock, fire hazard or malfunction. Please install proper power supply cables before using the air conditioner.
- ▶ The grounding resistance should comply with national electric safety regulations.
- ▷ Air Conditioner should be properly grounded. Incorrect grounding may cause electric shock.
- Do not put through the power before finishing installation.
- Do install the circuit breaker. If not, it may cause malfunction.
- ▷ An all-pole disconnection switch having a contact separation of at least 3mm in all poles should be connected in fixed wiring.
- Circuit breaker should be included magnet buckle and heating buckle function. It can protect the overload and circuitshort.

#### SAFETY PRECAUTIONS

## (!) CAUTION (!)

- ▶ Instructions for installation and use of this product are provided by the manufacturer.
- Select a location which is out of reach for children and far away from animals or plants. If it is unavoidable, please add the fence for safety purpose.
- ▶ The indoor unit should be installed close to the wall. Don't use unqualified power cord.
- ▷ If the length of power connection wire is insufficient, please contact the supplier for a new one.
- ▶ The appliance must be positioned so that the plug is accessible.
- ▷ For the air conditioner with plug, the plug should be reachable after finishing installation.
- ▶ For the air conditioner without plug, a circuit breaker must be installed in the line.
- ▷ The yellow-green wire in air conditioner is grounding wire, which can't be used for other purposes. The air conditioner is the first class electric appliance. It must be properly grounder with specialized grounding device by a professional. Please make sure it is always grounded effectively, otherwise it may cause electric shock.
- ➤ The temperature of refrigerant circuit will be high, please keep the interconnection cable away from the copper tube.

## 

## Operation and Maintenance

- Description This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- ▶ Children shall not play with the appliance.
- ▶ Cleaning and user maintenance shall not be made by children without supervision.
- ▷ If the supply cord is damaged, it must be replaced by the manufacturer, it's service agent or similarly qualified persons in order to avoid a hazard.
- Do not connect air conditioner to multipurpose socket. Otherwise, it may cause fire hazard
- Do disconnect power supply when cleaning air conditioner. Otherwise, it may cause electric shock. Do not wash the air conditioner with water to avoid electric shock.
- Do not spray water on indoor unit. It may cause electric shock or malfunction. Do not repair air conditioner by yourself. It may cause electric shock or damage. Please contact dealer when you need to repair air conditioner.
- ▶ After removing the filter, do not touch the fins to avoid injury.
- Do not extend fingers or objects into air inlet or air outlet. It may cause personal injury or damage.



#### **SAFETY PRECAUTIONS**



#### WARNING



# Operation and Maintenance

- Do not spill water on the remote controller, otherwise the remote controller may be broken.
- Do not use fire or hair dryer to dry the filter to avoid deformation or fire hazard. Do not block air outlet or air inlet. It may cause malfunction.
- Do not step on top panel of outdoor unit, or put heavy objects. It may cause damage or personal injury. When below phenomenon occurs, please turn off air conditioner and disconnect power immediately, and then contact the dealer or qualified professionals for service:
  - ▶ Power cord is overheating or damaged.
  - ▶ There's abnormal sound during operation.
  - ▶ Circuit breaker trips off frequently.
  - ▶ Air conditioner gives off burning smell.
  - ▶ Indoor unit is leaking.

#### **UV-C LAMP FUNCTION INSTRUCTION**

## (!) CAUTION (!)

This appliance contains a UV emitter. Do not stare at the light source.

▶ This appliance contains a UV-C lamp.

- ▶ Read the maintenance instructions before opening the appliance.
- ▶ Details for cleaning and other user maintenance of the appliance:
  - Prior to cleaning or other maintenance, the appliance must be disconnected from the supply mains.
  - 2. Open the panel to take out the filter.
  - 3. Use a soft cotton cloth to wipe the quartz glass until it's clean.4. Reinstall the filter when it has been
  - Reinstall the filter when it has been cleaned and then close the panel cover.
- ▶ The method, frequency of cleaning, and necessary precautions to be taken:
- ▶ Cleaning method: wipe the quartz glass with soft cloth until the surface is clean.

Cleaning frequency:

clean it every 6 months;

the cleaning frequency can be properly adjusted according to the degree of air cleanliness.

Preventive measures:

- The unit must be turned off and the power must be cut off before cleaning. Otherwise, it may cause electric shock and damage by UV.
- Do not use volatile oil, alcohol, diluents or lacquer to clean the UV-C lamp. Otherwise, the UV-C lamp may be damaged.
- 3. Do not touch the fins of indoor unit to prevent scalding.
- 4. Do not scratch the surface of glass when wiping it.
- ▷ Unintended use of the appliance or damage to the housing may result in the escape of dangerous UV-C radiation. UV-C radiation may, even in small doses, cause harm to the eyes and skin.
- ▶ Appliances that are obviously damaged must not be operated.
- ▷ Before opening doors and access panels bearing the ultraviolet radiation hazard Symbol for the conducting user maintenance, it is recommended to disconnect the power.


> UV-C barriers bearing the ultraviolet radiation hazard symbol should not be removed.

## ! CAUTION !

Do not operate the UV-C emitter when it is removed from the appliance.

➤ To avoid any dangerous situations, the user shall not replace the UV-C lamp, which must be performed by the manufacturer or the professionals of the maintenance or similar department.





# Safety precautions for installing and relocating the unit

To ensure safety, please be mindful of the following precautions.



#### **WARNING**



- When installing or relocating the unit, be sure to keep the refrigerant circuit free from air or substances other than the specified refrigerant.
- Any presence of air or other foreign substance in the refrigerant circuit will cause system pressure rise or compressor rupture, resulting in injury.
- When installing or moving this unit, do not charge the refrigerant which is not comply with that on the nameplate or unqualified refrigerant.
  - Otherwise, it may cause abnormal operation, wrong action, mechanical malfunction or even serious safety accident.
- When refrigerant needs to be recovered during relocating or repairing the unit, besure that the unit is running in cooling mode. Then, fully close the valve at high

#### WARNING



pressure side (liquid valve). About 30-40 seconds later, fully close the valve at low pressure side (gas valve), immediately stop the unit and disconnect power. Please note that the time for refrigerant recovery should not exceed 1 minute.

If refrigerant recovery takes too much time, air may be sucked in and cause pressure rise or compressor rupture, resulting in injury.

- During refrigerant recovery, make sure that liquid valve and gas valve are fully closed and power is disconnected before detaching the connection pipe.
  - If compressor starts running when stop valve is open and connection pipe is not yet connected, air will be sucked in and cause pressure rise or compressor rupture, resulting in injury.
- ➤ When installing the unit, make sure that connection pipe is securely connected before the compressor starts running.
  - If compressor starts running when stop valve is open and connection pipe is not yet connected, air will be sucked in and cause pressure rise or compressor rupture, resulting in injury.
- ▷ Prohibit installing the unit at the place where there may be leaked corrosive gas or flammable gas.
  - If there is leaked gas around the unit, it may cause explosion and other accidents.
- Do not use extension cords for electrical connections. If the electric wire is not long enough, please contact a local service center authorized and ask for a proper electric wire. Poor connections may lead to electric shock or fire.
- Use the specified types of wires for electrical connections between the indoor and outdoor units. Firmly clamp the wires so that their

#### **Tools for installation**

- 1. Level meter
- 2. Screw driver
- 3. Impact drill
- 4. Drill head
- 5. Open-end wrench
- 6. Pipe cutter
- 7. Leakage detector
- 8. Universal meter
- 9. Inner hexagon spanner
- 10. Measuring tape
- 11. Pipe expander
- 12. Torque wrench
- 13. Vacuum pump
- 14. Pressure meter



#### NOTICE

- ▶ Please contact the local agent fo installation.
- Don't use unqualified power cold. 

  →

# SELECTION OF INSTALLATION LOCATION

#### **Basic requirement**

Installing the unit in the following places may cause malfunction. If it is unavoidable, please consult the local dealer:

- 1. The place with strong heat sources, vapors, flammable or explosive gas, or volatile objects spread in the air.
- 2. The place with high-frequency devices (such as welding machine, medical equipment).
- 3. The place near coast area.
- 4. The place with oil or fumes in the air.
- 5. The place with sulfureted gas.
- 6. Other places with special circumstances.
- 7. The appliance shall not be installed in the laundry.
- 8. It's not allowed to be installed on the unstable or motive base structure (such as truck) or in the corrosive environment (such as chemical factory).

#### Indoor unit

- 1. There should be no obstruction near air inlet and air outlet.
- 2. Select a location where the condensation water can be dispersed easily and won't affect other people.
- 3. Select a location which is convenient to connect the outdoor unit and near the power socket.
- 4. Select a location which is out of reach for children.
- 5. The location should be able to withstand the weight of indoor unit and won't increase noise and vibration.
- 6. The appliance must be installed 2.5 m above floor.
- 7. Don't install the indoor unit right above the electric appliance.
- 8. Please try your best to keep way from fluorescent lamp.

#### SELECTION OF INSTALLATION LOCATION

#### Safety precaution

- 1. Must follow the electric safety regulations when installing the unit.
- According to the local safety regulations, use qualified power supply circuit and air switch.
- 3. Make sure the power supply matches with the requirement of air conditioner. Unstable power supply or incorrect wiring or malfunction. Please install proper power supply cables before using the air conditioner.
- 4. Properly connect the live wire, neutral wire and grounding wire of power socket.
- 5. Be sure to cut off the power supply before proceeding any work related to electricity and safety.
- 6. Do not put through the power before finishing installation.
- 7. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- The temperature of refrigerant circuit will be high, please keep the interconnection cable away from the copper tube.
- The appliance shall be installed in accordance with national wiring regulations.

#### **Grounding requirement**

- The air conditioner is the first class electric appliance. It must be properly grounded with specialized grounding device by a professional. Please make sure it is always grounded effectively, otherwise it may cause electric shock.
- 2. The yellow-green wire in air conditioner is grounding wire, which can't be used for other purposes.
- 3. The grounding resistance should comply with national electric safety regulations.
- 4. The appliance must be positioned so that the plug is accessible.
- 5. An all-pole disconnection switch having a contact separation of at least 3 mm in all poles should be connected in fixed wiring.

#### Step 1:


#### Choose installation location

Recommend the installation location to the client and then confirm it with the client.

#### Step 2:

#### Install wall-mounting frame

- Hang the wall-mounting frame on the wall; adjust it in horizontal position with the level meter and then point out the screw fixing holes on the wall.
- Drill the screw fixing holes on the wall with impact drill (the specification of drill head should be the same as the plastic expansion particle) and then fill the plastic expansion particles in the holes.
- 3. Fix the wall-mounting frame on the wall with tapping screws and then check if the frame is firmly installed by pulling the frame. If the plastic expansion particle is loose, please drill another fixing hole nearby.



#### Step 3:

#### Open piping hole

1. Choose the position of piping hole according to the direction of outlet pipe. The position of piping hole should be a little lower than the wall-mounted frame, shown as below.


#### NOTICE

- ▶ The wall panel is for illustrative purposes only, please refer to the actual installation.
- ▶ Please refer to the actual circumstances for the number of screws and the position of screws.
- 2. When installation is finished, pull the mounting plate with hand to confirm whether it is fixed tightly. The force distribution for all screws should be uniform.
- 3. Open a piping hole with the diameter of Ø55 or Ø70 on the selected outlet pipe position. In order to drain smoothly, slan t the piping hole on the wall slightly downward to the outdoor side with the gradient of 5-10°.



#### **NOTICE**


Pay attention to dust prevention and take rele vant safety measures when opening the hole.



#### Step 4:


#### **Outlet pipe**

1. The pipe can be led out in the direction of right, rear right, left or rear left.






2. When select leading out the pipe from left or right, please cut off the corresponding hole on the bottom case.




#### Step 5:

#### Connect the pipe of indoor unit

- 1. Aim the pipe joint at the corresponding bellmouth.
- 2. Pretighten the union nut with hand.




3. Adjust the torque force by referring to the following sheet. Place the open-end wrench on the pipe joint and place the torque wrench on the union nut. Tighten the union nut with torque wrench.



Hex nut diameter	Tightening torque (N.m)
1/4"	15~20
3/8"	30~40
1/2"	45~55
5/8"	60~65
3/4"	70~75


4. Wrap the indoor pipe and joint of connection pipe with insulating pipe, and then wrap it with tape.




#### Step 6:

#### Install drain hose

1. Connect the drain hose to the outlet pipe of indoor unit.



2. Bind the joint with tape.





#### NOTICE

insulating pipe

- ▶ Add insulating pipe in the indoor drain hose in order to prevent condensation.
- ▶ The plastic expansion particles are not provided.


#### Step 7:

#### Connect wire of indoor unit




#### **NOTICE**


- ▶ All wires of indoor unit and outdoor unit should be connected by a professional.
- ▶ If the length of power connection wire is insufficient, please contact the supplier for a new one. Avoid extending the wire by yourself.
- ▶ For the air conditioner with plug, the plug should be reachable after finishing installation.
- ▶ For the air conditioner without plug, an air switch must be installed in the line. The air switch should be all-pole parting and the contact parting distance should be more than 3mm.
- 1. Open the panel, remove the screw on the wiring cover and then take down the cover.



Make the power connection wire go through the cable-cross hole at the back of indoor unit and then pull it out from the front side.



 Remove the wire clip; connect the power connection wire to the wiring terminal according to the color; tighten the screw and then fix the power connection wire with wire clip.






#### **NOTICE**

- ▶ The wiring board is for reference only, please refer to the actual one.
- 4. Put wiring cover back and then tighten the screw.
- 5. Close the panel.

#### Step 8:


#### Bind up pipe

1. Bind up the connection pipe, power cord and drain hose with the band.



2. Reserve a certain length of drain hose and power cord for installation when binding them. When binding to a certain degree, separate the indoor power and then separate the drain hose.





- 3. Bind them evenly
- 4. The liquid pipe and gas pipe should be bound separately at the end.




#### NOTICE

- ➤ The power cord and control wire can't be crossed or winding.
- ➤ The drain hose should be bound at the bottom.



#### Hang the indoor unit

- 1. Put the bound pipes in the wall pipe and then make them pass through the wall hole.
- 2. Hang the indoor unit on the wall-mounting frame.
- 3. Stuff the gap between pipes and wall hole with sealing gum.
- 4. Fix the wall pipe.
- 5. Check if the indoor unit is installed firmly and closed to the wall.





#### **NOTICE**

Do not bend the drain hose too excessively in order to prevent blocking.

#### **CLEAN AND MAINTENANCE**

### $\bigvee$

#### WARNING



- ➤ Turn off the air conditioner and disconnect the power before cleaning the air conditioner to avoid electric shock.
- Do not wash the air conditioner with water to avoid electric shock.
- Do not use volatile liquid to clean the air conditioner.
- Do not use liquid or corrosive detergent to clean the appliance and do not splash water or other liquid onto it, otherwise, it may damage the plastic components, even cause electric shock.

#### Clean surface of indoor unit

When the surface of indoor unit is dirty, it is recommended to use a soft dry cloth or wet cloth to wipe it.



#### NOTICE

Do not remove the panel when cleaning it.

#### Clean filter

#### 1. Remove filter.

Press the spring fasteners at both sides in the direction indicated by the arrows. Meanwhile, lift up the filter so that it is separated from the fasteners.

Pull the filter forward and remove it.



#### Clean filter

#### 2. Clean filter.

Use clear water to wash it or dust catcher to clean it. If the filter is very dirty (such as grease), use warm water (45 °C) dissolved with neutral detergent to clean it, and then put it in a shady place to dry it.





#### 3. Install filter.

After cleaning, reinstall the filter in reverse order. Push it along the guide rails at both sides and then press the left and right edges of the filter. Refit the filter in the direction indicated by the arrows.



#### $\bigwedge$

#### **WARNING**



- ➤ The filter should be cleaned every three months. If there is much dust in the operation environment, clean frequency can be increased.
- ▶ After removing the filter, do not touch the fins to avoid injury.
- Do not use fire or hair dryer to dry the filter to avoid deformation or fire hazard.



#### Clean surface of indoor unit



#### NOTICE

#### Checking before use-season

- 1. Check whether air inlets and air outlets are blocked.
- 2. Check whether air switch, plug and socket are in good condition.
- 3. Check whether filter is clean.
- 4. Check whether mounting bracket for outdoor unit is damaged or corroded. If yes, please contact dealer.
- 5. Check whether drainage pipe is damaged

#### Checking after use-season

- Disconnect power supply.
- 2. Clean filter and indoor unit's panel.
- Check whether mounting bracket for outdo or unit is damaged or corroded. If yes, please contact dealer.

#### **Notice for recovery**

- 1. Many packing materials are recyclable materials. Please dispose them in appropriat e recycling unit.
- 2. If you want to dispose the air conditioner, please contact local dealer or consultant service center for the correct disposal method.

#### **ERROR CODE**

#### **Error Code**

When air conditioner status is abnormal, temperature indicator on indoor unit will blink to display corresponding error code. Please refer to below list for identification of error code.

Error Code	Troubleshooting	
E1, E5, E6,	It can be eliminated after restarting the unit. If not, please contact qualified professionals for service.	
	Please contact qualified professionals for service.	



#### NOTICE

If there're other error codes, please contact qualified professionals for service.

# CHECKED ITEMS BEFORE MAINTENANCE

#### General phenomenon analysis

Please check below items before asking for maintenance. If the malfunction still can't be eliminated, please contact local dealer or qualified professionals.

## CHECKED ITEMS BEFORE MAINTENANCE

Phenomenon	Check items	Solution
Filefioffiefion	Whether it's interfered severely	
	(such as static electricity, stable voltage?)	Pull out the plug. Reinsert the plug after about 3min, and then turn on the unit again.
	Whether remote co ntroller is within the signal receiving range?	Signal receiving range is 8m.
Indoor unit contt	Whether there are obstacles?	Remove obstacles.
Indoor unit can't receive remote controller's signal or remote controller has	Whether remote controller is pointing at the receiving window?	Select proper angle and point the remote controller at the receiving window on indoor unit.
no action.	ls sensitivity of remote controller low; fuzzy display or no display?	Check the batteries. If the power of batteries is too low, please rep-lace them.
	No display when operating remote controller?	Check whether remote controller appears to be damaged. If yes, replace it.
	Fluorescent lamp in room?	Take the remote controller close to indoor unit. Turn off the fluorescent lamp and then try it again.
	Air inlet or air outlet of indoor unit is blocked?	Eliminate obstacles.
No air emitted from indoor unit	Under heating mode, indoor temperature is reached to set temperature?	After reaching to set temperature, indoor unit will stop blowing out air.
	Heating mode is turned on just now?	In order to prevent blowing out cold air, indoor unit will be started after delaying for several minutes, which is a normal phenomenon.
	Power failure?	Wait until power recovery.
	Is plug loose?	Reinsert the plug.
Air conditioner can't		Ask professional to replace air switch or fuse.
operate	Wiring has malfunction?	Ask professional to replace it.
	Unit has restarted immediately after stopping operation?	Wait for 3 min, and then turn on the unit again.
	Whether the function setting for remote controller is correct?	Reset the function.
Mist is emitted from indoor unit's air outlet	Indoor temperature and humidity is high?	Because indoor air is cooled rapidly. After a while, indoor temperature and humidity will be decrease and mist will disappear.
Odours are emitted	Whether there's odour source, such as furniture and cigarette, etc.	Eliminate the odour source. Clean the filter.
Set temperature can't be adjusted	Your required temperature exceeds the set temperature range?	Set temperature range: 16 °C~30 °C. Set temperature range in HEAT mode: 8 °C ~30 °C .
	Voltage is too low?	Wait until the voltage resumes normal.
Cooling (heating)	Filter is dirty?	Clean the filter.
effect is not good.	Set temperature is in proper range?	Adjust temperature to proper range.
	Door and window are open?	Close door and window.
Air conditioner operates abnormally	Whether there's interference, such as thunder, wireless devices, etc.	Disconnect power, put back power, and then turn on the unit again.
"Water flowing" noise	Air conditioner is turned on or turned off just now?	The noise is the sound of refrigerant flowing inside the unit, which is a normal phenomenon.
Cracking noise	Air conditioner is turned on or turned off just now?	This is the sound of friction caused by expansion and or contraction of panel or other parts due to the change of temperature.
	Whether the air guide louver has been adjusted?	Disconnect the power for 3s and then connect the power; if the problem still exits, disconnect the power, reinstall the air guide louver (install the upper air guide louver and then install the lower air guide louver) and then connect the power.



### WARNING




When below phenomenon occurs, please turn off air conditioner and disconnect power immediately, and then contact the dealer or qualified professionals for service.

- ▶ Power cord is overheating or damaged.
- ▶ There's abnormal sound during operation.
- ▶ Air switch trips off frequently.
- ▶ Air conditioner gives off burning smell.
- ▶ Indoor unit is leaking.

Do not repair or refit the air conditioner by yourself.

If the air conditioner operates under abnormal conditions, it may cause malfunction, electric shock or fire hazard.

#### CONSTRUCTION OF THE INDOOR UNIT



#### **DISPLAY**

Heat mode	*
Cool mode	*
Dry mode	۲,۲
Temp. indicator	26
Power indicator	υ
Humidity indicator	%



#### **NOTICE**

- > This is the general introduction and the color of indicator is only for reference. Please refer to the actual display.
- ▶ Display content may be different from the actual. Please refer to the actual display.

# OPERATION AND INTRODUCTION OF REMOTE CONTROLLER



# BUTTONS ON REMOTE CONTROLLER





# INTRODUCTION FOR ICONS ON DISPLAY SCREEN

<b>Q</b> Quiet		9	Quiet	
	FAN AUTO		Set fan speed	
	<b>®</b>		Turbo mode	
	<b>♠</b>		Send signal	
	Operation mode		Auto mode	
			Cool mode	
			Dry mode	
	oera	ধ্য	Fan mode	
	ō	*	Heat mode	
	<u> </u>	22	X-FAN function	
	3	<u></u>	Humidity control	
	į	1	Power limiting operation*	
	8	8.5	Set temperature	
	<b>&amp;</b>		fl Indoor ambient temp.	
			িখ্ৰ Indoor ambient humidity	
	ON OFF		TIMER ON / TIMER OFF	
	88	:88	Set time	
	71	<u> </u>	Left & right swing	
	=	O	Up & down swing	
	Ę	3	Child lock	
	*		Fast cool	
	*		Health and UVC functions	
	WiFi		Wi-Fi function	
	-\$* -\$\; - <b>;</b> •		LED	
			Auto LED	
			I feel	
	C3		Sleep mode	
	企		Two-way ventilation function	



#### NOTICE

\* This function is only available for some



#### INTRODUCTION FOR BUTTONS ON REMOTE CONTROLLER

#### **NOTICE**

- Description This is a general use remote controller. It could be used for the air conditioner with multifunction. For the functions which the model doesn't have, if press the corresponding button on the remote controller, the unit will keep the original running status.
- ▷ After putting through the power, the air conditioner will give out a sound. Power indicator « ① » is ON. After that, you can operate the air conditioner by using remote controller.
- ▶ Under on status, pressing the button on the remote controller, the signal icon « » on the display of remote controller will blink once and the air condition-er will give out a «di» sound, which means the signal has been sent to the air conditioner.

### (4)

#### **«ON/OFF»** button

Press this button to turn on the unit.

Press this button again to turn off the unit.

#### «MODE» button

Press this button to select your required operation mode.

- > When selecting auto mode, air conditioner will operate automatically according to the sensed temperature. Press «Fan» button can adjust fan speed. Press « ☞ / ᆗ) » button can adjust fan blowing angle.
- ▶ After selecting cool mode, air conditioner will operate under cool mode. Press « + » or « » button to adjust set temperature. Press

- «Fan» button to adjust fan speed. Press « 河 / 寛 » button to adjust fan blowing angle. When selecting dry mode, the air conditioner operates at low speed under dry mode. Under dry mode, fan speed can't be adjusted. Press « 河 / 寛 » button to adjust fan blowing angle.
- When selecting fan mode, the air conditioner will only blow fan, no cooling and no heating. Press «Fan» button to adjust fan speed. Press « ¬¬ / ¬) » button to adjust fan blowing angle.
- > When selecting heat mode, the air conditioner operates under heat mode. Press « + » or « » button to adjust set temperature. Press «Fan» button to adjust fan speed. Press « ☞ / 亨) » button to adjust fan blowing angle.



#### NOTICE

- ▷ For preventing cold air, after starting up heat mode, indoor unit will delay 1~5 minutes to blow air (Actual delay time depends on indoor ambient temperature).
- ▶ Set temperature can be adjusted under AUTO mode.
- Set temperature range from remote controller: 16 ~ 30 °C (61 − 86 °F).
- Set temperature range from remote controller under HEAT mode: 8~30 °C (46-86 °F).
- ▶ This mode indicator is not available for some models.
- > Cooling only unit won't receive heat mode signal. If setting heat mode with remote controller, press « ∪ » button can't start up the unit.

#### «FAN» button



■ Low speed, ■■ Low-Medium speed, ■■■ Medium speed, ■■■■ Medium-High speed, ■■■■ High speed, ⑤ TURBO speed, ♠ Quiet speed.

#### **NOTICE**

- ▶ It's low fan speed under dry mode.
- ➤ X-FAN function Hold fan speed button for 2s in cool or dry mode, the icon « ※ » is displayed and the in- door fan will continue operation for a few minutes in order to dry the indoor unit even though you have turned off the unit. After energization, X-FAN OFF is defaulted. X-FAN is not available in auto, fan or heat mode.
- ▶ This function indicates that moisture on evaporator of indoor unit will be blowed after the unit is stopped to avoid mould.
- ➤ Having set X-FAN function on: After turning off the
- ▶ unit by pressing « ① » button indoor fan will continue running for a few minutes. at low speed. In this per- iod, Hold fan speed button for 2s to stop indoor fan directly.
- Description Having set X-FAN function off: After turning off the unit by pressing « ₺ » button, the complete unit will be off directly.

#### «+/-» button

Press « + » or « - » button once increase or decrease set temperature 1 °C (°F). Holding « + » or « - » button, 2s later, set temperature on remote controller will change quickly. On releasing button after setting is finished, temperature indicator on indoor unit will change accordingly.

#### (F)

#### «Wi-Fi» button

Press «Wi-Fi» button to turn on «Wi-Fi» function, «Wi-Fi» icon will be displayed on the remote controller; Hold «Wi-Fi» button for 5s to turn off WiFi function and «Wi-Fi» icon will disappear. Under off status, press «Mode» and «Wi-Fi» buttons simultaneously for 1s, Wi-Fi module will restore factory settings.

#### NOTICE

This function is only available for some models.

#### «Health» button

Press this button to turn on or turn off the health function and UVC lamp in operation status.



- ➤ When selecting « ♣ » with remote controller, CH SMART-ion filter (Cold Plasma) will be turn on.
- ▶ When selecting « □ » with remote controller, CH UV Cleaner (UVC lamp) will be turn on.
- ▷ When selecting « ⑤ » with remote controller, CH SMART-ion filter (Cold Plasma) and CH UV Cleaner (UVC lamp) will be turn on together.



### «UD-swing» button

Press this button can select up & down swing angle. Fan blow angle can be selected circularly as below:

- ➤ When selecting « <sup>©</sup> », air conditioner is blowing fan automatically. Horizontal louver will automat-ically swing up & down at maximum angle.
- Description Number > When selecting « -0, -0, -0, -0, 0, 0, ∞, a ir conditioner is blowing fan at fixed position. Horizontal louver will stop at the fixed position.
- ▶ Hold « ③ » button above 2s to set your required swing angle. When reaching your required angle, release the button.

#### **NOTICE**

- Press this button continuously more than 2s, the main unit will swing back and forth from up to down, and then loosen the button, the unit will stop swinging and present position of guide louver will be kept immedi-ately.
- Dunder swing up and down mode, when the status is switched from off to « ♥0 », if press this button again 2s later, « ♥0 » status will switch to off status directly; if press this button again within 2s, the change of swing status will also depend on the circulation sequence stated above.

### «Humidity» button

Under cooling mode, press this button can select humidity control with cooling mode, smart dehumidification with cooling mode, and general cooling mode, and they can be set to operate circularly.



▶ When humidity control with cooling mode is set, the remote controller will display « ② », and humidity value «88» and «%» icon will blink for 5s; you can press «+» and «-» buttons to set the humidity value within 5s.

Under humidity control with cooling mode, humidity setting range for the remote controller: 40%-80%.

Temperature can be adjusted under humidity control with cooling mode.

➤ When smart dehumidification with cooling mode is set, the remote controller will display « ② »; the remote controller and indoor unit will display «Ao» for 5 seconds.

Temperature can be adjusted under smart dehumidification with cooling mode.

The humidity for smart dehumidification is automatically adjusted according to human body comfort; no need to set the humidity manually.

Under dry mode, press this button can select humidity control with dehumidification mode, continuous dehumidification mode, general dehumidification mode, and they can be set to operate circularly.

humidify control with continuous dehumi dification general with dehumidification mode with dehumidification mode

➤ When humidity control with dehumidification mode is set, the remote controller will display « ② », «%» and humidity value «88»; you can press «+» and «-» buttons to set the humidity value.

Humidity setting range for the remote controller: 30%-70%.

Temperature can't be adjusted under humidity control with dehumidification mode.

- ➤ When continuous dehumidification is set, the remote controller will display « ② »; the remote controller and indoor unit will display «Co». Temperature can't be adjusted under continuous dehumidification mode.
- Under continous dehumidification mode, the unit always works under dehumidification status; no need to set temperature and humidity.



#### **NOTICE**

- ➤ The air conditioner is mainly used for controlling the te-mperature, while the humidity control is the auxiliary function. The humidity will be affected by the factors such as indoor and outdoor environment, degree of indoor sealing and indoor flow.
- ➤ When the set humidity is higher than current atmospheric humidity, the set humidity can't be reached.
- ▷ If the humidity sensor is with malfunction, humidity setting under cooling mode or dehumidification mode will stop and the unit operates under general cooling mode or dehumidification mode.

#### «LR-swing» button

Press this button can select left & right swing angle. Fan blow angle can be selected circularly as below:





#### NOTICE

- ▶ Press this button continuously more than 2s, the main unit will swing back and forth from left to right, and then loosen the button, the unit will stop swinging and present position of guide louver will be kept immediately.
- D Under swing left and right mode, when the status is switched from off to ➡, if press this button again 2s later, ➡ status will switch to off status directly; if press this button again within 2s, the change of swing status will also depend on the circulation sequence stated above.
- ➤ This function only applicable for some models.

#### (0)

#### «TIMER» button

At ON status, press this button once can set TIMER OFF. The character of HOUR and OFF will flash. Press «+» or «-» button within 5s can adjust the time of TIMER OFF. After each pressing of «+» or «-» button, time will increase or decrease half an hour. When holding «+» or «-» button, 2s later, the time will change quickly until to reach to your required time. After that, press «Timer» button to confirm it. The character of HOUR and OFF won't flash again.

Cancel TIMER OFF: Press «Timer» button again under TIMER OFF status.

At OFF status, press this button once can set TIMER ON. Please refer to TIMER off for detailed operation.

Cancel TIMER ON: Press «Timer» button again under TIMER ON status.

#### **NOTICE**

- ▶ Time setting range: 0.5-24 hours.
- ➤ Time interval between two operations can't exceed 5s. Otherwise, remote controller will exit the setting status automatically.

#### (C)

#### Кнопка «Sleep»

Press this button, can select Sleep 1 (  $\bigcirc$  ), Sleep 2 (  $\bigcirc$  2), Sleep 3 (  $\bigcirc$  3) and cancel the Sleep, circulate between these, after electrified, Sleep Cancel is defaulted.

- Sleep 1 is Sleep mode 1, in Cool modes: sleep status after run for one hour, the main unit setting temperature will increase 1, two hours, setting temperature increased 2, then the unit will run at this setting temperature; In Heat mode: sleep status after run for one hour, the setting temperature will decrease 1, two hours, setting temperature will decrease 2, then the unit will run at this setting temperature.
- Sleep 2 is sleep mode 2, that is air conditioner will run according to the presetting a group of sleep temperature curve.
- Sleep 3 the sleep curve setting under Sleep mode by DIY;
- ▶ (1) Under Sleep 3 mode, press «Health» button for a long time, remote controller



enters into user individuation sleep setting status, at this time, the time of remote controller will display «1 HOUR», the setting temperature «88» will display the correspond-ing temperature of last setting sleep curve and blink (The first entering will display according to the initial curve setting value of original factory);

- (2) Adjust « + » and « » button, could change the corresponding setting temperature, after adjusted, press «Health» button for confirmation;
- > (3) At this time, 1hour will be automatically increased at the timer position on the remote control, (that are «2 HOUR» or «3 HOUR» or «8 HOUR»), the place of setting temperature «88» will display the corresponding temperature of last setting sleep curve and blink;
- ▷ (4) Repeat the above step (2)~(3) operation, until 8 hours temperature setting finished, sleep,curve setting finished, at this time, the remote controller will resume the original timer display; temperature display will resume to original setting temperature. Sleep 3 the sleep curve setting under Sleep mode by DIY could be inquired:
- ➤ The user could accord to sleep curve setting method to inquire the presetting sleep curve, enter into user individuation sleep setting status, but do not change the temperature, press «Health» button directly for confirmation.



#### NOTICE

▶ In the above presetting or enquiry procedure, if continuously within 10s, there is no button pressed, the sleep curve setting within 10s, there is no button pressed, the sleep curve setting status will be automatically quit and resume to display the original displaying. In the presetting or enquiry procedure, press « On/Off » button, «Mode» button, «Timer» button or «Sleep» button, the sleep curve setting or enquiry status will quit similarly.



#### «Light» button

Press this button to control the LED status on the displayer, the circulation change is as follow:

When selecting «  $\dot{\dot{Q}}$  » (Auto LED) with remote controller, LED indicator on indoor unit will adjust the luminance automatically according to the ambient intensity of illumination.

#### FUNCTION INTRODUCTION FOR COMBINATION BUTTONS

#### **Energy-saving function**

Under cooling mode, press «Mode» and «Timer» buttons simultaneously to start up or turn off energy-saving function. When energy-saving function is started up, «SE» will be shown on remote controller, and air conditioner will adjust the set temperature automatically according to exfactory setting to reach to the best energy-saving effect.

Press «Mode» and «Timer» buttons simultaneously again to exit energy-saving function.



#### NOTICE

- Under energy-saving function, fan speed is defaulted at auto speed and it can't be adjusted.
- ▶ Under energy-saving function, set temperature can't be adjusted.
- Sleep function and energy-saving function can't operate at the same time. If energysaving function has been set under cool mode, press «Sleep» button will cancel energy-saving function. If sleep function has been set under cool mode, start up the energy-saving function will cancel sleep function



#### Child lock function

Hold « On/Off » and « - » buttons simultaneously for 3s to turn on or turn off child lock function. When child lock function is on, « ⊕ » icon is displayed on remote controller. If you operate the remote con-troller, the « ⊕ » icon will blink three times without sending signal to the unit.

# Temperature display switchover function °C (Centigrade), °F (Fahrenheit)

Under OFF status, hold «Mode» and « - » buttons simultaneously for 3s to switch temperature displaybetween °C and °F.



#### function

function is for limiting power of the whole unit. Press «Mode» and «Sleep» buttons simultaneously, the remote controller will circularly display as the following:



- ▶ Maximum power limited under the mode is lower than that of mode.
- ▷ If you want to cancel the power limiting function, press «Mode» and «Sleep» buttons simultaneously till the icon in remote controller is not displayed.
- ➤ When the remote controller is turned off, power limiting function is cancelled. If you want to activate the function, please repress «Mode» and «Sleep» buttons simultaneously.
- ▶ If the current power is lower than the maximum power of \$\overline{\ov
- ▶ For the model with one outdoor unit and two indoor units, if any one of indoor units enters into power limiting function, the outdoor unit will enter into the set limiting power mode of indoor unit; when two indoor units enter into power limiting mode, then the power of outdoor unit will be limited according to the lower power of the two indoor units.



#### NOTICE

▶ This button is only available for the model with such function.



#### FUNCTION INTRODUCTION FOR COMBINATION BUTTONS



#### Indoor ambient temperature or humidity display

By holding « On/Off » and « 膏) » buttons simultane-ously, you can see indoor ambient temperature or indoor ambient humidity on indoor unit's display. The setting on remote controlleris selected circularly as below:



- ▶ When selecting « ② » with remote controller, temperature indicator on indoor unit displays indoor ambient temperature.
- ▶ When selecting « ② » with remote controller, temperature indicator on indoor unit displays indoor ambient humidity.



#### NOTICE

- ▶ The ambient humidity value is only for reference. Eg: If the humidity value is «0%», there may be malfunction for the humidity detection board. Please contact local service provider.
- ▶ There may be some measuring deviation for humidity detection and photosensitiveness detection.

#### Clean reminder function of filter

The reminder function is defaulted to be OFF. Hold « On/Off » and « 膏) » buttons simultaneously for 5s to turn it on. The buzzer will give out sound for 0.5s and the dual-8 nixie tube on the display will be on for 3s; Once the reminder function is turned on, when the air conditioner has reached to the set time, the dual-8 nixie tube will flash about 30s when the unit is turned on each time to remind the user to clean the filter; you can turn off this cycle reminder by holding « On/Off » and « 膏) » buttons simultaneously for 5s and then the air conditioner will count time again.



#### **NOTICE**

- Donce the reminder function is turned on, only this cycle reminder can be cleared.
- ▶ This function is only available for some models.

#### Volume control of IDU Buzzer

Press «Mode» and « 灬 », buttons simultaneously to reduce the sound level of the indoor unit' buzzer.



#### NOTICE

▶ This function is only available for some models.



#### (※) Fast cool function

Press « On/Off » and « + » buttons simultaneously under cooling mode can select 25 °C (77 °F) fast cool-ing mode, 16 °C (61 °F) fast cooling mode and normal cooling mode circularly. « \* » icon will be displayed on the remote controller under fast cooling mode. Once it enters into fast cooling mode, the fan speed is auto fan and the set temperature is 25 °C (77 °F) or 16 °C (61 °F). At this time, the set temperature flashes to display for 5s. In the flashing period, press « + » or « - » button to adjust the set temperature. Press «Fan» button to adjust the fan speed. If the set temperature and the fan speed haven't been adjusted during that time, the remote controller and the indoor unit will operate under current set temperature and fan speed for 20 minutes. 20 minutes later, the set temperature and the fan speed for the remote controller and the indoor unit will turn to the status before quick cooling.

#### **FUNCTION INTRODUCTION FOR COMBINATION BUTTONS**



#### NOTICE

- ▷ If the set temperature and the fan speed have been adjusted during the operation under fast cooling mode, the unit will exit from the fast cooling mode. Then the indoor unit operates continuously under the adjusted status.
- ▶ Fast cooling function is only applicable for some models. If this function is unavailable for this indoor unit, 20 minutes later, the remote controller will turn back to the status before fast cooling. Indoor unit operates continuously according to current status. At this time, status of indoor unit and the display status on the remote controller may be different.
- ▶ This function is only available for some models.

#### **Auto clean function**

Under unit off status, hold «Mode» and « ) buttons simultaneously for 5s to turn on or turn off the auto clean function. When the auto clean function is turned on, indoor unit displays «CL». During the auto clean process of evaporator, the unit will perform fast cooling or fast heating. There may be some noise, which is the sound of flowing liquid or thermal expansion or cold shrinkage. The air conditioner may blow cool or warm air, which is a normal phenomenon. During cleaning process, please make sure the room is well ventilated to avoid affecting the comfort.



#### NOTICE

- ➤ The auto clean function can only work under normal ambient temperature. If the room is dusty, clean it once a month; if not, clean it once every three months. After the auto clean function is turned on, you can leave the room. When auto clean is finished, the air conditioner will enter standby status.
- ➤ This function is only available for some models.

#### Night mode

Under cooling or heating mode, when turning on sleep mode and turn to low speed or quiet notch, the outdoor unit would enter into night mode.



#### **NOTICE**

- ➤ When you feel that the cooling and heating effect is poor, please press «Fan» button to other fan speed or press «Sleep» button to exit the night mode.
- ▶ The night mode can only work under normal ambient temperature.
- ➤ This function is only available for some models.



#### I FEEL Function

Press «Health» and « + » buttons simultaneously to start I FEEL function and « I will be displayed on the remote controller. After this function is set, the remote controller will send the detected ambient temperature to the controller and the unit will automatically adjust the indoor temperature according to the detected temperature. Press «Health» and « + » buttons simultaneously again to turn off I FEEL function and « I will disappear.

▷ Please put the remote controller near user when this function is set. Do not put the remote controller near the object of high temperature or low temperature in order to avoid detecting inaccurate ambient temperature.When I FEEL function is turned on, the remote controller should be put within the area where indoor unit can receive the signal sent by the remote controller.

#### Two-way ventilation function


Under turning on, press «Mode» and «Health» buttons simultaneously to start up or turn off two-way ventilation function. When two-way ventilation function is started up, & will be shown on remote controller, and the light of the two-way ventilation system is turned on. Fan



speed will be adjusted according to the fan speed of air conditioner.

Under turning off, press «Mode» and «Health» buttons simultaneously to start up or turn off two – way ventilation function only. When two-way ventilation function is started up, ₤ will be shown on remote controller, and the light of the two-way ventilation system is turned on. Fan speed will be adjusted according to fan button on remote controller.

## Replacement of batteries in remote controller




- Press the back side of remote controller marked with « 
  », as shown in the fig, and then push out the cover of battery box along the arrow direction.
- Replace two 7# (AAA 1.5V) dry batteries, and make sure the position of «+» polar and «-» polar are correct.
- 3. Reinstall the cover of battery box.




#### **NOTICE**


- During operation, point the remote control signal sender at the receiving window on indoor unit.
- ➤ The distance between signal sender and receiving window should be no more than 8m, and there should be no obstacles between them.
- Signal may be interfered easily in the room where there is fluorescent lamp or wireless telephone; remote controller should be close to indoor unit during operation.
- ▶ Replace new batteries of the same model when replacement is required.
- ▶ When you don't use remote controller for a long time, please take out the batteries.
- ▶ If the display on remote controller is fuzzy or there's no display, please replace batteries.

## CONSTRUCTION OF THE OUTDOOR UNIT





▶ Actual product may be different from above graphics, please refer to actual product.



# afety precautions for installing and relocating the unit

To ensure safety, please be mindful of the following precautions.

## ① CAUTION ①

When installing or relocating the unit, be sure to keep the refrigerant circuit free from air or substances other than the specified refrigerant.

Any presence of air or other foreign substance in the refrigerant circuit will cause system pressure rise or compressor rupture, resulting in injury.

When in stalling or moving this unit, do not charge the refrigerant which is not comply with that on the nameplate or unqualified refrigerant.

Otherwise, it may cause abnormal operation, wrong action, mechanical malfunction or even serious safety accident.

When refrigerant needs to be recovered during relocating or repairing the unit, be sure that the unit is running in cooling

## (!) CAUTION (!)

mode. Then, fully close the valve at high pressure side (liquid valve). About 30-40 seconds later, fully close the valve at low pressure side (gas valve), immediately stop the unit and disconnect power. Please note that the time for refrigerant recovery should not exceed 1 minute.

If refrigerant recovery takes too much time, air may be sucked in and cause pressure rise or compressor rupture, resulting in injury.

During refrigerant recovery, make sure that liquid valve and gas valve are fully closed and power is disconnected before detaching the connection pipe.

If compressor starts running when stop valve is open and connection pipe is not yet connected, air will be sucked in and cause pressure rise or compressor rupture, resulting in injury.

When installing the unit, make sure that connection pipe is securely connected before the compressor starts running.

If compressor starts running when stop valve is open and connection pipe is not yet connected, air will be sucked in and cause pressure rise or compressor rupture, resulting in injury.

Prohibit installing the unit at the place where there may be leaked corrosive gas or flammable gas.

If there is leaked gas around the unit, it may cause explosion and other accidents.

Do not use extension cords for electrical connections. If the electric wire is not long enough, please contact a local service center authorized and ask for a proper electric wire.

Poor connections may lead to electric shock or fire.

Use the specified types of wires for electrical connections between the indoor and outdoor units. Firmly clamp the wires so that their terminals receive no external stresses.

Electric wires with insufficient capacity, wrong wire connections and insecure wire terminals may cause electric shock or fire.

#### **Tools for installation**

- 1. Level meter
- 2. Screw driver
- 3. Impact drill
- 4. Drill head
- 5. Open-end wrench
- 6. Pipe cutter
- 7. Leakage detector
- 8. Universal meter
- 9. Inner hexagon spanner
- 10. Measuring tape
- 11. Pipe expander
- 12. Torque wrench
- 13. Vacuum pump
- 14. Pressure meter



#### NOTICE

- ▶ Please contact the local agent for installation.
- Don't use unqualified power cold.

# SELECTION OF INSTALLATION LOCATION

#### **Basic requirement**

Installing the unit in the following places may cause malfunction. If it is unavoidable, please consuit the local dealer:

- 1. The place with strong heat sources, vapors, flammable or explosive gas, or volatile objects spread in the air.
- The place with high-frequen cy devices (such as welding machine, medical equipment).
- 3. The place near coast area.
- 4. The place with oil or fumes in the air.
- 5. The place with sulfureted gas.
- 6. Other places with special circumstances.
- 7. The appliance shall not be installed in the laundry.
- 8. It's not allowed to be installed on the unstable or motive base structure (such as truck) or in the corrosive environment (such as chemical factory).

#### **Outdoor unit**

- Select a location where the noise and outflow air emitted by the outdoor unit will not affect neighborhood.
- The location should be well ventilated and dry, in which the outdoor unit won't be exposed directly to sunlight or strong wind.
- 3. The location should be able to withstand the weight of outdoor unit.
- 4. Make sure that the installation follows the requirement of installation dimension diagram.
- Select a location which is out of reach for children and far away from animals or plants. If it is unavoidable, please add the fence for safety purpose.

#### **Safety precaution**

- 1. Must follow the electric safety regulations when installing the unit.
- According to the local safety regulations, use qualified power supply circuit and air switch.
- Make sure the power supply matches with the requirement of air conditioner. Unstable power supply or incorrect wiring or malfunction. Please install proper power supply cables before using the air conditioner.
- 4. Properly connect the live wire, neutral wire and grounding wire of power socket.
- 5. Be sure to cut off the power supply before proceeding any work related to electricity and safety.
- 6. Do not put through the power before finishing installation.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- 8. The temperature of refrigerant circuit will be high, please keep the interconnection cable away from the copper tube.
- The appliance shall be installed in accordance with national wiring regulations.

#### **Grounding requirement**

- 1. The air conditioner is the first class electric appliance. It must be properly grounding with specialized grounding device by a professional. Please make sure it is always grounded effectively, otherwise it may cause electric shock.
- The yellow-green wire in air conditioner is grounding wire, which can't be used for other purposes.
- 3. The grounding resistance should comply with national electric safety regulations.
- 4. The appliance must be positioned so that the plug is accessible.
- An all-pole disconnection switch having a contact separation of at least 3mm in all poles should be connected in fixed wiring.

#### Air switch capacity

Including an air switch with suitable capacity, please note the following t able. Air switch should be included magnet buckle and heat ing buckle function, it can protect the circuits hort and overload.


(Caution: please do not use the fuse only for protect the circuit)

Air-conditioner	Air switch capacity
09K, 12K	10A
18K	16A
24K	25A

# Step 1: Fix the support of outdoor unit

(select it according to the actual installation situation)

- Select installation location according to the house structure.
- 2. Fix the support of outdoor unit on the sele cted location with expansion screws.





#### **NOTICE**

- ▶ Take sufficient protective measures when installin g the outdoor unit.
- ▶ Make sure the support can withstand at least four times of the unit weight.
- ➤ The outdoor unit should be installed at least 3cm above the floor in order to install drain joint.(for the model with heating tube, the installation height should be no less than 20cm.)
- ▶ For the unit with cooling capacity of 2300 W ~ 5000 W, 6 expansion screws are needed; for the unit with cooling capacity of 6000 W~8000 W, 8 expansion screws are needed; for the unit with cooling capacity of 10000 W~16000 W, 10 expansion screws are needed.

#### Step 2:

#### Install drain joint


(only for some models)

- Connect the outdoor drain joint into the hole on the chassis, as shown in the picture below.
- 2. Connect the drain hose into the drain vent.



#### NOTICE


Description As for the shape of drainage joint, please refer to the current product. Do not install the drainage joint in the severe cold area. Otherwise, it will be frosted and then cause malfunction.



#### Step 3:

#### Fix outdoor unit

- 1. Place the outdoor unit on the support.
- 2. Fix the foot holes of outdoor unit with bolts.



#### Step 4:


#### Connect indoor and outdoor pipes

1. Remove the screw on the right handle of outdoor unit and then remove the handle.






2. Remove the screw cap of valve and aim the pipe joint at the bellmouth of pipe.



3. Pretighten the union nut with hand.




4. Tighten the union nut with torque wrench by referring to the sheet below.

Hex nut diameter	Tightening torque (N m)
1/4"	15~20
3/8"	30~40
1/2"	45~55
5/8"	60~65
3/4"	70~75

#### Step 5:

#### Connect outdoor electric wire

 Remove the wire clip; connect the power connection wire and signal control wire (only for cooling and heating unit) to the wiring terminal according to the color; fix them with screws.



#### **NOTICE**

- ▶ The wiring board is for reference only, please refer to the actual one.
- 2. Fix the power connection wire and signal control wire with wire clip (only for cooling and heating unit).



#### NOTICE


- ▶ After tighten the screw, pull the power cord slightly to check if it is firm.
- ▶ Never cut the power connection wire to prolong or shorten the distance.


## INSTALLATION OF OUTDOOR UNIT

## Step 6:

## Neaten the pipes

- 1. The pipes should be placed along the wall, bent reasonably and hidden possibly. Min. semidiameter of bending the pipe is 10cm.
- 2. If the outdoor unit is higher than the wall hole, you must set a U-shaped curve in the pipe before pipe goes into the room, in order to prevent rain from getting into the room.







## **NOTICE**


▶ The through-wall height of drain hose should not be higher than the outlet pipe hole of indoor unit.



▶ The water outlet can't be placed in water in order to drain smoothly.




⊳ Slant the drain hose slightly downwards. The drain hose can't be curved, raised and fluctuant, etc.



## **TEST AND OPERATION**

### Use vacuum pump

- Remove the valve caps on the liquid valve and gas valve and the nut of refrigerant charging vent.
- 2. Connect the charging hose of piezometer to the refrigerant charging vent of gas valve and then connect the other charging hose to the vacuum pump.
- 3. Open the piezometer completely and operate for 10–15 min to check if the pressure of piezo- meter remains in -0.1 MPa.
- 4. Close the vacuum pump and maintain this status for 1-2 min to check if the pressure of piezometer remains in -0.1 MPa. If the pressure decreases, there may be leakage.
- 5. Remove the piezometer, open the valve core of liquid valve and gas valve completely with inner hexagon spanner.
- 6. Tighten the screw caps of valves and refrigerant charging vent.
- 7. Reinstall the handle.



## Leakage detection

- 1. With leakage detector: Check if there is leakage with leakage detector.
- 2. With soap water: If leakage detector is not available, please use soap water for leakage detection. Apply soap water at the suspected position and keep the soap water for more than 3min. If there are air bubbles coming out of this position, there's a leakage.

## **Check after installation**

▶ Check according to the following requirement after finishing installation.

	- :: 16 ::
Items to be checked	Possible malfunction
Has the unit been	The unit may drop, shake
installed firmly?	or emit noise.
	It may cause insufficient
gerant leakage test? Is heat insulation of	cooling (heating) capacity.
pipeline sufficient?	It may cause condensation and water dripping.
	It may cause condensation
Is water drained well?	and water dripping.
Is the voltage of power	and water ampoing.
supply according to the	It may cause malfunction
voltage marked on the	or damage the parts.
nameplate?	, i
Is electric wiring and	It may cause malfunction
pipeline installed	or damage the parts.
correctly?	,
Is the unit grounded	It may cause electric
securely?	leakage.
Does the power cord follow the specification?	It may cause malfunction
	or damage the parts.
Is there any obstruction in the air inlet and	It may cause insufficient
outlet?	cooling(heating) capacity.
The dust and sundries	
caused during	It may cause malfunction
installation are	or damage the parts.
removed?	
The gas valve and liquid	It may cause insufficient
valve of connection pipe	cooling (heating) capacity.
are open completely?	
Is the inlet and outlet	It may cause insufficient
of piping hole been covered?	cooling (heating) capacity or waste electricity.
covereu:	or waste electricity.

## **Test operation**

#### 1. Preparation of test operation

- ▶ The client approves the air conditioner.
- ▷ Specify the important notes for air conditioner to the client.

#### 2. Method of test operation

- Put through the power, press ON/OFF buton on the remote controller to start operation.
- Press MODE button to select AUTO, COOL, DRY, FAN and HEAT to check whether the operation is normal or not.
- ▶ If the ambient temperature is lower than 16°C, the air conditioner can't start cooling.

## **CONFIGURATION OF CONNECTION PIPE**

- 1. Standard length of connection pipe: 5 m, 7.5 m, 8 m.
- 2. Min. length of connection pipe. For the unit with standard connection pipe of 5 m, there is no limitation for the min length of connection pipe. For the unit with standard connection pipe of 7.5 m and 8 m, the min length of connection pipe is 3 m.
- 3. Max. length of connection pipe is shown as below.

## Max. length of connection pipe

Cooling capacity	Max. length of connection pipe (m)
5000 Btu/h (1465 W)	15
7000 Btu/h (2051 W)	15
9000 Btu/h (2637 W)	15
12000 Btu/h (3516 W)	20
18000 Btu/h (5274 W)	25
24000 Btu/h (7032 W)	25
28000 Btu/h (8204 W)	30
36000 Btu/h (10548 W)	30
42000 Btu/h (12306 W)	30
48000 Btu/h (14064 W)	30

- 4. The calculation method of additional refrigerant oil and refrigerant charging amount after prolonging connection pipe After the length of connection pipe is prolonged for 10m at the basis of standard length, you should add 5ml of refrigerant oil for each additional 5m of connection pipe. The calculation method of additional refrigerant charging amount (on the basis of liquid pipe):
  - (1) Additional refrigerant charging amount = prolonged length of liquid pipe × additional refrigerant charging amount per meter
  - (2) Basing on the length of standard pipe, add refrigerant according to the requirement as shown in the table. The additional refrigerant charging amount per meter is different according to the diameter of liquid pipe. See Sheet.

# Additional refrigerant charging amount for R32

Piping size	j size	Indoor unit throttle	Outdoor u	Outdoor unit throttle
Liquid pipe	Gas pipe	Cooling only, cooling and heating (g / m)	Cooling only (g / m)	Cooling and heating (g / m)
1/4"	3/8" or 1/2"	16	12	16
1/4" or 3/8"	5/8" or 3/4"	07	12	04
1/2"	3/4" or 7/8"	80	24	96
5/8"	1" or 11/4"	136	84	96
3/4"	I	200	200	200
1/8/.	Í	280	280	280



## **NOTICE**

The additional refrigerant charging amount in Sheet is recommended value, not compulsory.



## PIPE EXPANDING METHOD




## **NOTICE**

Improper pipe expanding is the main cause of refrigerant leakage. Please expand the pipe according to the following steps:

## A: Cut the pipe

- ▶ Confirm the pipe length according to the distance of indoor unit and outdoor unit.
- ▷ Cut the required pipe with pipe cutter.



#### **B:** Remove the burrs


▶ Remove the burrs with shaper and prevent the burrs from getting into the pipe.



# C: Put on suitable insulating pipe


## D: Put on the union nut

▶ Remove the union nut on the indoor connection pipe and outdoor valve; install the union nut on the pipe.



## E: Expand the port

▶ Expand the port with expander.






## NOTICE

«A» is different according to the diameter, please refer to the sheet below:

Outer diameter	A (n	nm)
(mm)	max	min
Ø6 - 6,35 (1/4")	1,3	0,7
Ø9 – 9,52 (3/8")	1,6	1,0
Ø12 – 12,7 (1/2")	1,8	1,0
Ø15,8 – 16 (5/8")	2,4	2,2

## F: Inspection

▶ Check the quality of expanding port. If there is any blemish, expand the port again according to the steps above.



#### SPECIALIST'S MANUAL

## The following checks shall be applied to installations using flammable refrigerants:

- be the charge size is in accordance with the room size within which the refrigerant containing parts are installed;
- by the ventilation machinery and outlets are operating adequately and are not obstructed;
- ▶ if an indirect refrigerating circuit is being used, the secondary circuit shall be checked for the presence of refrigerant;
- ▷ marking to the equipment continues to be visible and legible. Markings and signs that are illegible shall be corrected;
- refrigeration pipe or components are installed in a position where they are unlikely to be exposed to any substance which may corrode refrigerant containing components, unless the components are constructed of materials which are inherently resistant to being corroded or are suitably protected against being so corroded.

Repair and maintenance to electrical components shall include initial safety checks and component inspection procedures. If a fault exists that could compromise safety, then no electrical supply shall be connected to the circuit until it is satisfactorily dealt with. If the fault cannot be corrected immediately but it is necessary to continue operation, an adequate temporary solution shall be used. This shall be reported to the owner of the equipment so all parties are advised.

#### Initial safety checks shall include:

- that capacitors are discharged: this shall be done in a safe manner to avoid possibility of sparking;
- that no live electrical components and wiring are exposed while charging, recovering or purging the system;
- ▶ that there is continuity of earth bonding.

#### Checking for presence of refrigerant

The area shall be checked with an appropriate refrigerant detector prior to and during work, to ensure the technician is aware of potentially toxic or flammable atmospheres. Ensure that the leak detection equipment being used is suitable for use with all applicable refrigerants,

i.e. non-sparking, adequately sealed or intrinsically safe.

#### Presence of fire extinguisher

If any hot work is to be conducted on the refrigeration equipment or any associated parts, appropriate fire extinguishing equipment shall be available to hand. Have a dry powder or CO<sub>2</sub> fire extinguisher adjacent to the charging area.

#### Ventilated area

Ensure that the area is in the open or that it is adequately ventilated before breaking into the system or conducting any hot work. A degree of ventilation shall continue during the period that the work is carried out. The ventilation should safely disperse any released refrigerant and preferably expel it externally into the atmosphere.

#### Checks to the refrigeration equipment

Where electrical components are being changed, they shall be fit for the purpose and to the correct specification. At all times the manufacturer's maintenance and service guidelines shall be followed. If in doubt, consult the manufacturer's technical department for assistance.

#### Checks to electrical devices

- that capacitors are discharged: this shall be done in a safe manner to avoid possibility of sparking:
- that no live electrical components and wiring are exposed while charging, recovering or purging the system.

#### Repairs to sealed components

During repairs to sealed components, all electrical supplies shall be disconnected from the equipment being worked upon prior to any removal of sealed covers, etc. If it is absolutely necessary to have an electrical supply to equipment during servicing, then a permanently operating form of leak detection shall be located at the most critical point to warn of a potentially hazardous situation.

Particular attention shall be paid to the following to ensure that by working on electrical components, the casing is not altered in such a way that the level of protection is



affected. This shall include damage to cables, excessive number of connections, terminals not made to original specification, damage to seals, incorrect fitting of glands, etc.

- ▶ Ensure that the apparatus is mounted securely.
- ▷ Ensure that seals or sealing materials have not degraded to the point that they no longer serve the purpose of preventing the ingress of flammable atmospheres. Replacement parts shall be in accordance with the manufacturer's specifications.



## **NOTICE**

The use of silicon sealant can inhibit the effectiveness of some types of leak detection equipment. Intrinsically safe components do not have to be isolated prior to working on them.

#### Repair to intrinsically safe components

Do not apply any permanent inductive or capacitance loads to the circuit without ensuring that this will not exceed the permissible voltage and current permitted for the equipment in use.

Intrinsically safe components are the only types that can be worked on while live in the presence of a flammable atmosphere. The test apparatus shall be at the correct rating.

Replace components only with parts specified by the manufacturer. Other parts may result in the ignition of refrigerant in the atmosphere from a leak.

#### Cabling

Check that cabling will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges or any other adverse environmental effects. The check shall also take into account the effects of aging or continual vibration from sources such as compressors or fans.

### Detection of flammable refrigerants

Under no circumstances shall potential sources of ignition be used in the searching for or detection of refrigerant leaks. A halide torch (or any other detector using a naked flame) shall not be used.

#### Leak detection methods

Leak detection fluids are suitable for use with most refrigerants but the use of detergents 40 containing chlorine shall be avoided as the chlorine may react with the refrigerant and corrode the copper pipe-work.

#### Decommissioning

Before carrying out this procedure, it is essential that the technician is completely familiar with the equipment and all its detail. It is recommended good practice that all refrigerants are recovered safely. Prior to the task being carried out, an oil and refrigerant sample shall be taken in case analysis is required prior to re-use of reclaimed refrigerant. It is essential that electrical power is available before the task is commenced.

- A. Become familiar with the equipment and its operation.
- B. Isolate system electrically.
- C. Before attempting the procedure, ensure that:
  - ➤ mechanical handling equipment is available, if required, for handling refrigerant cylinders;
  - ▶ all personal protective equipment is available and being used correctly:
  - b the recovery process is supervised at all times by a competent person;
  - > recovery equipment and cylinders conform to the appropriate standards.
- D. Pump down refrigerant system, if possible.
- E. If a vacuum is not possible, make a manifold so that refrigerant can be removed from various parts of the system.
- F. Make sure that cylinder is situated on the scales before recovery takes place.
- G. Start the recovery machine and operate in accordance with manufacturer's instructions.
- H. Do not overfill cylinders. (No more than 80% volume liquid charge).
- I. Do not exceed the maximum working pressure of the cylinder, even temporarily.
- J. When the cylinders have been filled correctly and the process completed, make sure that the cylinders and the equipment are removed from site promptly and all isolation valves on the equipment are closed off.
- K. Recovered refrigerant shall not be charged into another refrigeration system unless it has been cleaned and checked.

#### Labelling

Equipment shall be labelled stating that it has been de-commissioned and emptied of refrigerant. The label shall be dated and signed. For appliances containing flammable refrigerants, ensure that there are labels on the equipment stating the equipment contains flammable refrigerant.

## Recovery

When removing refrigerant from a system, either for servicing or decommissioning, it is recommended good practice that all refrigerants are removed safely.

When transferring refrigerant into cylinders, ensure that only appropriate refrigerant recovery cylinders are employed. Ensure that the correct number of cylinders for holding the total system charge are available. All cylinders to be used are designated for the recovered refrigerant and labelled for that refrigerant (i.e. special cylinders for the recovery of refrigerant). Cylinders shall be complete with pressure-relief valve and associated shut-off valves in good working order. Empty recovery cylinders are evacuated and, if possible, cooled before recovery occurs.

The recovery equipment shall be in good working order with a set of instructions concerning the equipment that is at hand and shall be suitable for the recovery of all appropriate refrigerants including, when applicable, flammable refrigerants. In addition, a set of calibrated weighing scales shall be available and in good working order. Hoses shall be complete with leak-free disconnect couplings and in good condition. Before using the recovery machine, check that it is in satisfactory working order, has been properly maintained and that any associated electrical components are sealed to prevent ignition in the event of a refrigerant release. Consult manufacturer if in doubt.

The recovered refrigerant shall be returned to the refrigerant supplier in the correct recovery cylinder, and the relevant waste transfer note arranged. Do not mix refrigerants in recovery units and especially not in cylinders.


If compressors or compressor oils are to be removed, ensure that they have been evacuated to an acceptable level to make certain that

flammable refrigerant does not remain within the lubricant. The evacuation process shall be carried out prior to returning the compressor to the suppliers. Only electric heating to the compressor body shall be employed to accelerate this process. When oil is drained from a system, it shall be carried out safely.



## **EWPE SMART WI-FI CONTROL APPLICATION**

## Wi-Fi app and set up



## Download and installation

Scan the QR code or search **Ewpe Smart** in the application



market to download and install it. When the application is installed, register the account and add the device to achieve long-distance control and LAN control of smart home appliances.

For more information, please refer to  $\mathbf{Help}$  in app.

## Set up process

- Scan the QR code above with your smart phone to download and install the Wi-Fi application directly.
- Open the Wi-Fi app and click **Sign up** for registration.
- Sign in through the prompt interface, you can also enter the homepage and click the profile picture at the left upper corner to sign in.
- 4. Click + at the right upper corner of homepage to add device and select **AC**.
- 5. After selecting  $\mathbf{AC}$ , you can select different

## Operating systems

Requirement for user's smart phone:



iOS system Support iOS7.0 and above version



Android system
Support Android 4.4 and above version

reset tools according to actual situation. The app interface will provide relevant operation instructions for different tools.

- Reset the air conditioner (refer to the operation instructions in app interface) and click Next to add home appliance automatically (Wi-Fi password shall need to be inputed).
- 7. Or after setting and activating the air conditioner, click Add appliance manually at the right upper corner to select the wireless network for controlling the device. Then confirm family Wi-Fi and arrange configuration.
- After finalising device reset and filling in the correct information, search device and arrange configuration.

## Main function settings

In the homepage, click the device in the device list and enter the device into the operation interface.

Set mode, temperature and fan speed to your desired choice.

## **Advanced settings**

Click **FUNC** in the lower left corner in device operation interface to enter advanced settings

42

## **Swing Settings**

Click **Up down swing** or **Left right swing** to turn on or turn off swing function. Click the arrow at the right lower corner of icon to enter the set swing range.

## **Preset Setting**

Select **Timer** to set preset times of your choice

## Other function settings

#### Homepage menu

Click the profile picture at the left upper corner of homepage and set each function in the following menu.

#### Scene

Click **Scene** and then you can operate the devices in the preset scene.

#### Home management

Click **Home management** to create or manage family. You can also add family members according to the registered account.

#### Help

Click **Help** and view the operation instructions of the app.

M	10de <b>l</b>		CH-S09FTXAN-**	CH-S12FTXAN-**	CH-S18FTXAN-**	CH-S24FTXAN-**	
0:	cooling	kW	2.7	3.51	5.30	7.10	
Capacity	heating	kW	3.0	3.81	5.6	7.30	
Powe	er supply			~ 220–240	V/50Hz/1P		
D-4-J:	cooling	kW	0.67	0.838	1.472	2.03	
Rated capacity	heating	kW	0.68	0.929	1.365	1.87	
Air flow r	rate	m³/h	610/570/540/470/ 440/420/390/180	720/600/570/530/ 500/460/430/320	1000/880/760/650/ 620/600/550/260	1000/850/760/580/ 520/450/400/280	
Soud level rate	IDU (min/ mid/ max)	db(A)	38/37/34/31/ 26/23/22/19	45/42/40/37/ 34/29/26/23	45/42/40/37/ 34/29/26/23	48/44/41/40/ 38/36/33/27	
	ODU	db(A)	50	56	59	59	
Refrigerant type			R32				
Overall dimensions	IDU	mm	837×293×200	837×293×200	993×311×222	993×311×222	
(width/ height/depth)	ODU	mm	732×555×330	873X561X376	873×555×376	958×660×402	
117.1.L.	IDU	kg	9.5	9.5	13.0	13.0	
Weight	ODU	kg	25.0	35.0	37.0	45.0	
Compresso	r type			Rot	tary		
Dehumidific	cation	I/h	0.8	1.4	1.8	2.4	
Temperature range	cooling	°C			~50		
Refrigerant v		ka	0.53	0.57	~30 0.95	1.4	
system kg			<u> </u>				
Liquid line diameter inch		6.35/1/4"	6.35/1/4"	6.35/1/4"	6.35/1/4"		
Gas line dia		mm/ inch	9.52/3/8"	9.52/3/8"	12.7/1/2"	15.88/5/8"	
"Max diffe	x. height erence''		10	10	10	10	
Max. pi	ping length	1	15	20	25	25	
Distance b	etween fix	ings	455	528	528	570	


\*Cooper&Hunter is constantly working on improvement by pouring their products, so what information given in this manual, may be changedwithout prior notice to consumers.

2024/9