

Front caster replacing method

1-1 Back off 4pcs screws by Large torque E-driver with percussive mode; scrap the screws.



Front caster replacing method

1-2 If has no Large torque E-driver or air-screw driver, please heat screw with around 120 ° C/20S, then back off 4pcs screws by E-driver. scrap the screws.



2. Using foam protect tube, knock caster by rubber hammer to remove casters; and scrap them.



3. To assemble new caster to tube by rubber hammer, use foam to protect caster.



4. To add glue on screws and fix new front caster assembly by new screws

