


RÄJÄYTYSKUVA • SPRÄNGSKISS • EXPLODED VIEW



OSAT • DELAR • PARTS

No.	Parts Name	No.	Parts Name	No.	Parts Name
1	Gear Sider Plate Assembly	19	Brake Seat	37	Chain Ring
2	Brake Side Plate Assembly	20	Friction Disc	38	Hex Nut
3	Gear Case Assembly	21	Ratchet Disc	39	Reversing Pawl
4	Disc Gear Assembly	22	Clutch Spring	40	Spring Seat
5	Disc Gear Assembly	23	Snap Ring	41	Spring
6	Lever Handle Cover	24	Brake Ring	42	Top Hook-6t
7	Brake Cover	25	Lock Nut	43	Top Hook Frame Set-6t
8	Top Hook Assembly	26	Reversing Ratchet	44	Top Hook Pin-6t
9	Safety Latch Assembly	27	Bushing	45	Top Hook Wheel
10	Bottom Hook Assembly	28	Spring Washer	46	Bottom Hook Wheel Pin
11	Drive Shaft	29	Hex Head Screw	47	Bottom Hook Frame Set-6t
12	Snap Ring	30	Hand Wheel	48	Bottom Hook-9t
13	Splined Gear	31	Spring Washer	49	Top Hook Frame Set-9t
14	Top Hook Shaft	32	Cross Recessed Screw	50	Roller Needle
15	Chain Guide Cover	33	Castle Nut	51	Bottom Hook Pin-9t
16	Pawl Spring	34	Split Pin	52	Bottom Hook Frame Set-9t
17		35			
18		36			

Pawl

Load Chain

Snap Ring

Stripper